



Clarkson



What is Really in Aqueous Film Forming Foam & Does it Matter?

Raj Kamal Singh^{1,2}, Elizabeth Brown², Selma Mededovic Thagard¹, Thomas M. Holsen²

¹Plasma Research Laboratory, Department of Chemical and Biomolecular Engineering, Clarkson University, Potsdam, New York 13699, United States


²Department of Civil and Environmental Engineering, Clarkson University, Potsdam, New York 13699, United States

Email: rsingh@clarkson.edu

Outline

- Introduction
 - PFAS classification
 - Background
 - Motivation
- AFFF Characterization
- What happen upon AFFF oxidation
- AFFF treatment approach
- Plasma based water treatment
 - Plasma treatment for PFAS
 - Plasma treatment results
- Conclusion

Per- and Polyfluorinated alkyl substances (PFAS)




Per- and Polyfluorinated alkyl substances (PFAS)

- PFAS sources in the environment:
 - **Aqueous film forming foams (AFFF)** for firefighting activities at DoD sites, commercial airports, and industrial facilities
 - Industrial spills and dumping
 - Wastewater effluents
 - Leaky landfill
 - Disposal of household products
- Current drinking water health advisory levels for PFAS are **3-4 orders of magnitude lower** than concentrations measured at several U. S. Department of Defense sites.
- Long-chain PFAS ($C \geq 8$) are bio-accumulative and toxic. Therefore, manufacturing and usage of C8 AFFF is phased out.
- PFAS are **very recalcitrant** because of the stability of the C-F bond.
- USEPA requires AFFF to be free of long-chain PFAAs.




[Source: midwestadvocates.org](http://midwestadvocates.org)

PFAS contaminated sites: Current status



Source: saferchemicals.org

States With Numerical PFAS Limits



Source: Bloomberg Environment

US EPA – no standards

**US EPA health advisory limit:
70 ng/L for PFOA and PFOS**

Massachusetts PFAS standard: 20 ng/L for six PFAS (PFHxS, PFHpA, PFOA, PFOS, PFNA and PFDA)

Motivation

Activated carbon – relatively short breakthrough time and disposal of adsorbent.

Ion exchange – concentrated brine solution.

Advanced oxidation processes (UV/H₂O₂/O₃) – ineffective and/or prohibitively expensive.

Plasma: Generates both oxidants and reductants – reported to be more effective than other leading technologies for removal of PFAS from water.¹

Literature gap:


- No treatment technology available to **degrade** PFAS at **large-scale**.
- Efficient treatment of aqueous film-forming foams (AFFF).

Rationale:

- Can a pre-oxidation option prior to plasma be more efficient and cost effective?


¹Nzeribe et al., 2019 *Critic. Rev. Env. Sci. Tech.* **2019**, 49, 866 – 915.

C6 AFFF Characterization



	Total fluorine (mg/L)	TOP (mg/L)
Chemguard	430	2900
Phoscheck	380	1500
Ansulite	6140	10000
Fomtec	-	3000

Comparison between C8 and C6 AFFF



C6 Foam




C8 Foam



Very high concentration of PFHxS (C6) = 2.3 mg/L

Significant concentration of C8, C10, C12, C13 and C14 acids = 12 to 65 µg/L

PFAS Concentrations in AFFF Rinsate



AFFF Rinsate




PFAS precursors, Long- and short-chain PFAAs were detected in rinsate sample.

6:2 FTS detected in highest concentration.


What happen upon oxidation of AFFF?

Effect of dilution prior to heat-activated persulfate oxidation

100x diluted samples



Optimization of heat-activated persulfate oxidation



Optimized condition

Dilution factor for *Chemguard*: 1000 times

Phoscheck: 1000 times


Ansulite: 10000 times

Persulfate dose: 360 mM


Conversion >99%

PFAS concentrations in pre- and post-oxidized AFFF samples


Pre-oxidation



Post-oxidation



Insight from non-targeted (LC-QToF-MS) analysis: Hunting for Unknowns



Unknown compounds of detected mass (m/z)

586, 567, 638, 709, 780, 602, 569,
618, 451, 541, 686, 467, 483, 461,
510, 542, 581, 597, 483

Most abundant unknown PFAS precursor
in Ansulite (1000x diluted) sample

**Place and Field., 2012*

Treatment approach

Characterization of four AFFF samples

- PFAS – 20 PFAAs, 10 precursors
- Total oxidizable precursors (TOP)
- Total Fluorine (TF)

Optimization of heat-activated persulfate and other oxidation options


- Oxidant dose
- Dilution factor
- Treatment time

Plasma-treatment of oxidized AFFF samples

Optimization of reactor geometry and power input for degradation of PFAAs

Plasma-based Water Treatment (PWT)

- Plasma is a mixture of neutral species, positive ions, negative ions, and electrons.
- Electrical discharge plasmas are generated *directly in or above water*.



Pictures: Plasma Research Laboratory, Clarkson University

Advanced oxidation process (AOP)

Plasma

Oxidative species
($\cdot\text{OH}$, O , H_2O_2 , O_2 , $\cdot\text{HO}_2$)

Reductive species
(e_{aq}^- , e^- , H)

Can oxidize and
reduce organic and
inorganic compounds


Physical effect
(UV, electric field, shock wave, locally high temperature)

- PWT does not require chemical additives and produces no residual waste.


Performance of Pilot-scale Plasma Reactor

IDW – Investigation derived waste; 13 samples from different Air Force base

Removal efficiency



PFOA and PFOS removal



TOP – Total Oxidizable Precursors


Within 1 minute, PFOA and PFOS was degraded to below USEPA health advisory concentration (70 ng/L)

Mobile Plasma Trailer



Field Demonstration

~350 gallons of PFAS-impacted groundwater were treated at various reactor operating conditions (flowrates, no. of recycle events*)




Trailer Performance: Energy cost

Energy Requirements and Calculated Costs for Reducing the Initial PFOA+PFOS Concentration to below 70 ng/L




Test	Energy required (kWh)	Total cost	Cost/cycle	Cost/gallon
Well B				
0.3 gpm	4 (4 cycles)	\$ 0.48		
0.6 gpm	1 (1 cycle)	\$ 0.12	\$ 0.12/cycle	\$0.0067/gal
0.9 gpm	1 (1 cycle)	\$ 0.12		
Well C				
0.3 gpm	3 (3 cycles)	\$ 0.36	\$ 0.12/cycle	\$ 0.0067/gal
1.1 gpm	2 (2 cycles)	\$ 0.24		

*One cycle (18 gal of water) is defined as a single pass through the reactor from the influent tank.

Plasma treatment: Without pre-oxidation



Plasma Treatment: with Pre-oxidation



Conclusion

- Analysis of 20 PFAAs and 10 precursors in 4 different AFFF samples showed:
 - high concentrations of short-chained PFAAs
 - traces of long-chain PFAAs
 - a significant amount of PFAS precursors
- 6:2 FTS was present at high concentrations in all four AFFF samples.
- The AFFF sample with the highest concentrations of PFAS precursors can be fully oxidized (>99%) when diluted 10^3 to 10^4 times with a 360 mM $K_2S_2O_8$.
- After oxidation significantly higher concentrations of long-chain PFAAs were found (for PFOA concentrations increased by up to 700%).
- LC-QToF-MS analysis showed the presence of many unknown PFAS compounds in AFFF samples.
- To fully convert PFAS precursors to PFAAs, pre-oxidation of AFFF samples **may be required** prior to plasma treatment, which was proven to be an effective technology to destroy AFFF.

Acknowledgements

DoD Plasma group

Prof. Thomas Holsen (Post Doc Advisor)
Prof. Selma M. Thagard (Post Doc Advisor)
Dr. Sujan Fernando (CAARES Lab Director)
Dr. Raj Kamal Singh (Post Doc and Analyst)
Nicholas Multari (Lab Technician)
Chase Nau-Hix (Ph. D. Student)
Elizabeth Brown (Master's Student)



Clarkson

