

Examples of Issues that Have Been Examined using 3-D Modeling



Eric Suuberg

School of Engineering, Brown University
Providence, Rhode Island

With Kelly Pennell, Ozgur Bozkurt, Yijun Yao, Rui Shen, Niklas Novoa



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Some Examples of Calculations Using 3-D Models

- There are many models out there...
- Full 3-D Models- different calculational approaches
- How does the assumed nature of foundation breaches affect results?
- Diffusion dominated profiles of COCs in soil vs. predicting actual contaminant entry rates
- The role of advection



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Examples (Continued)

- What do models say about subslab sampling?
- Exploring complex geologies
- Safe distances and monitoring well placement
- Do you need to worry about soil moisture? Capillary zone? Rainfall events during soil gas sampling?
- Predicting transients
- Comparison to JE analysis
- Biodegradation




REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Modeling Approach

- A finite element computational package (Comsol) used to describe transport processes.



- Set finite element model domain.
- Typically assume a perimeter crack in the foundation.
- Assume “Stack Effect” creates an in-house negative pressure of 5 Pa.

Entry scenario	Models
No barrier entry	Little et al. (1971) (19), Dowdell (19), Jiang et al. (17), Sandars and Steen (11) (10)
Differential barrier layer connection	Little et al. (19) (18), Sandars and Steen (11) (10), VIA-ABQW (16)
No barrier entry into crawl space	CSOIL (17), CNIH 2000 (14), VIA-ABQW (16) (15)
Differential barrier into crawl space	VIA-ABQW (16), T & R model (7), IMPACT (13) (11), NIA (10)
Basement slab penetration	OCRA (12)
Foundation slab	Kyle and Ferguson (9), Ferguson et al. (8)
Crawl space	J-E model (17), Johnson et al. (19), Park (10), Murphy and Chao (12), The ASL model (Alonso and Johnson (2), 1977; Alonso (3); Alonso et al. (4) (1), The Brown model (Brodson et al. (14) (13)), Pomeroy et al. (10), Yao et al. (10) (5), Parker (6), CompFlow Bio (10), VIA-ABQW (16), Systech and Beckwith (11)

Lots of mathematical models of VI already in use worldwide

Source: Yao et al., *Env. Sci. Tech.*, 47, 2457-2470 (2013).

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Need to make important choices about how to handle above-ground effects.

Entry scenario	Models
Single CXT	Little et al. (18), OCRA (12), Sandars and Steen (10), J-E model (17), Johnson et al. (19), Jiang et al. (17), Parker (6), Dowdell (19), CompFlow Bio (10), Vergara and Beckwith (11), The ASL model (Alonso and Johnson (2), 1977; Alonso (3); Alonso et al. (4) (1), The Brown model (Brodson et al. (14) (13)), Pomeroy et al. (10), Yao et al. (10) (5)
Series CXTs	T & R model (7), CSOIL (17), VIA-ABQW (16) (15), CNIH 2000 (14), IMPACT (13) (11), Murphy and Chao (12), Owen and Cori (10) (10), Ferguson et al. (8), Kyle and Ferguson (9)
Combined series and parallel CXTs	VIA (10)

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures

BROWN

3-D Modeling Approach- Finite Element Solver (COMSOL)

Typically model
5 mm
perimeter
cracks

3-step solution method

1. Solve for gas flow through soil (Darcy's Law).
2. Solve for species transport via advection and diffusion.
3. Indoor air concentration is calculated using the species flow rate into the structure.

$$q = \frac{-K \nabla \phi}{\mu}$$

$$\phi = gz + \int \frac{dP}{\rho}$$

$$J_i = q \cdot C - D_{ij} \nabla C$$


$$D_{ij} = d_{ij}^{free} \cdot \frac{\eta_g^{10+3}}{\eta_r}$$

$$C_{indoor} = \frac{J_{T,ind}}{A_i \cdot V_i + Q_i}$$

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures


BROWN

Not the only 3-D model; Abreu and Johnson have developed a finite difference model



Grid spacing is variable - finer detail near cracks, source boundaries, and domain boundaries

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Really does not make much difference what sort of “cracks”, i.e., foundation breaches, are selected.

Yao et al., *Building and Environment*, 59, 417-425 (2013).

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Perimeter Crack		Wall Crack	
w/o capping	w/capping	w/capping	w/capping
— $k=10^{-10} \text{ m}^2$	● $k=10^{-10} \text{ m}^2$	○ $k=10^{-11} \text{ m}^2$	○ $k=10^{-11} \text{ m}^2$
- - - $k=10^{-11} \text{ m}^2$	■ $k=10^{-11} \text{ m}^2$	○ $k=10^{-12} \text{ m}^2$	○ $k=10^{-12} \text{ m}^2$
· · · $k=10^{-12} \text{ m}^2$	▲ $k=10^{-12} \text{ m}^2$	○ $k=10^{-13} \text{ m}^2$	○ $k=10^{-13} \text{ m}^2$

Yao et al., *Procedia Env. Sci.*, 4, 245-250 (2011).

Slab-on-grade COC entry rate (M_{ck})
is much more sensitive to capping around building than is
basement foundation (10m x 10 m foundation, 5 m apron)



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



BROWN

First Scenario Modeled: Homogeneous Soil Properties Throughout the Domain

Effect of Geology on Vapor Concentration Profiles:

Permeability	Soil Gas Entry Rate, Q (L/min)	P crack (Pa)	C crack (mg/m ³)	Mass flow rate (mg/sec)	C indoor air (µg/m ³)
High (10 ⁻¹⁰ m ²)	47.5	-5	75	5.89x10 ⁻²	1800
Moderate (10 ⁻¹¹ m ²)	4.75	-5	110	8.70x10 ⁻³	268
Low (10 ⁻¹⁴ m ²)	0.0048	-5	174	6.01x10 ⁻⁴	18.6

Groundwater at 8 m bgs

Basement depth 2m

GW TCE Concentration 54 µg/L

Diffusion Controlled Gradients

IN action level 1.2µg/m³


Steady state contaminant concentration gradient in soil mainly determined by diffusion



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures




BROWN




REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures




Interplay of advection and diffusion critical



$k=10^{-10} \text{ m}^2$
Draws in lots of air



$k=10^{-12} \text{ m}^2$
less of the "circle of influence" is in contaminated soil




$k=10^{-11} \text{ m}^2$
Draws in some air,
but most of "circle of influence" is contaminated soil

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Second Scenario Modeled: Active Sampling and Different Sampling Locations



Center of The House
6 inches beneath foundation
4 meters away from the building on legs

Source: SE upl, TCE



We simulated various sampling points at different depths and locations using a sampling rate of 6L/8hr.



Photos from O'Brien and Gere



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures




Second Scenario Modeled: Active Sampling and Different Sampling Locations

Where should samples be collected?

Center of The House Immediately beneath foundation	Permeability	C sampling location (mg/m ³)	C Indoor Air (mg/m ³)	Soil Gas Entry Rate (L/min)	C _{soil} /C _{sampling}
	High (10 ⁻¹⁰ m ²)	217	1.78	47.5	8.26x10 ⁻³
	Moderate (10 ⁻¹¹ m ²)	190	0.27	4.75	1.41x10 ⁻³
	Low (10 ⁻¹⁴ m ²)	174	1.86x10 ⁻³	0.0048	1.07x10 ⁻⁴

The concentration values at the sampling point for all three cases are very similar; however, higher soil gas flow rate through the crack carries more contaminant vapor into the building, causing higher indoor air concentration for high permeability cases.

Sub slab sampling may lead to incorrect conclusions about the indoor contaminant concentration.







REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures




Third Scenario: Effect of Different Soil Layers





REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures






Lateral distance between the edge of the building and the edge of the source (ft)

Lateral distance between the center of the building and the center of the source (ft)

Structure on an open field is fine...

But what about urban environments?



Parking lots, driveways

Adjacent capping and structures $k = 10^{-11} \text{ m}^2$

5 m driveway increases C_{indoor} by 30%, and adjacent house decreases it by 7%; for $k = 10^{-14}$, driveway has same effect but adjacent house has none.



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



How far is far enough??



$$D_c \left(\frac{\partial^2 C}{\partial x^2} + \frac{\partial^2 C}{\partial y^2} \right) = 0$$

Solved simple 2-D Laplace Equation

insignificant at lateral distances of only $\eta = 5$. The value of 100 ft given in the U.S. EPA guidance is a conservative upper limit for sites with groundwater shallower than 10 ft and diffusion-limited vapor transport. Our work suggests that the risk from breathing contaminated indoor air from subsurface contamination need only be investigated for buildings within a relatively short distance (e.g., within one or two residential sized lots) from the edge of the contamination plume.


Lowell and Eklund, 2004

Echoed in various guidance documents, but challenged by Abreu and Johnson, 2005 for homogeneous soils.

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



How close should GW Source measurements be?



Yao et al. *Vadose Zone Journal*, 2013

Subslab to Source Concentration


Unusually high source to slab attenuation can have an origin in GW sources that are not really that "close"

Consider 2 m deep basement, 4 m deep source, sampling GW at $r=5$ i.e., 20 m away, can lead to significant extra attenuation

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures





Redfield (Denver) Site



Indoor TCE levels for homes as a function of distance from measured groundwater plume edge (defined by DCE concentration)

Data from Folkes et al., AWMA Vapor Intrusion Conference, 2007

Depending upon action level, 100 ft may or may not be enough.



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures

BROWN

Capillary resistance probably needed to explain range of AF values in EPA database

Predictions without capillary fringe (blue lines)

Graph (a) shows normalized radon concentration (C₂/C₁) on a log scale from 10⁻⁵ to 10⁻¹ versus foundation/sewer depth (d_f/d_s) from 0.1 to 1. EPA data points are black dots. Two blue lines represent constant diffusion coefficient approximations for 3-D (D₁) and 2-D (D₂) models. The 3-D model shows a steeper decline than the 2-D model.

Predictions with capillary fringe (blue/green bars)

Graph (b) shows the same data as graph (a) but includes blue and green shaded regions representing models with capillary fringe. The EPA data points are better explained by these models, which show a more gradual decline in radon concentration with depth.

Yao et al., *Env. Sci. Tech.*, 47, 1425-1433 (2013)

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures

BROWN

Simple approaches to handling the capillary resistance do not work well.

In clay, moisture profile smooth, looks like uniform soil

The diagram shows a cross-section of a foundation on clay and sand. The clay layer has a thickness of 1 m. The sand layer has a thickness of 0.82 m. A narrow high-resistance capillary layer is shown in the sand. Moisture profiles are shown for the clay and sand layers, with a color scale from Min (blue) to Max (red). The clay profile is smooth, while the sand profile shows a sharp peak in the capillary layer.

In sand, high resistance forced in capillary layer


In sand, narrow high resistance capillary layer

In sand, more uniform resistance forced

Results using true soil moisture profile Results using 2-layer soil moisture profile approach of JE-type analysis


REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures





AF = 1×10^{-3}
(uniform loamy sand)

AF = 1.58×10^{-5}
for actual capillary zone
calculation




REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Rainfall Events

Shen et al., *Sci. Total Env.*, 437, 110 (2012)



Soil moisture profiles

In a week, moisture profile approaches initial profile

COC soil gas profiles

Hardly any effect on COC soil gas profile; bigger effect comes from rise in GW table
1 m depth of probes generally OK

Larger effect- air exchange rate?


Transient Situations

Darcy's Law

$$(x_r(1 - \eta_s) + x_r \eta_s) \frac{\partial p}{\partial t} = \nabla \cdot \left(\frac{k}{\mu_w} (\rho_w g \nabla z + \nabla p) \right)$$


Advection and Diffusion

$$\frac{\partial C_{i,s}}{\partial t} + \nabla \cdot (q_i C_{i,s} - D_{i2} \nabla C_{i,s}) + R_{i,s} = 0$$





With sudden appearance of a source at 8 m-shows typical response is diffusion rate determined

Note subsurface profiles take months/years to develop.



Note the very long timescales of response to "remediation"



EPA Screening Model Approach




- Based upon a 1-dimensional (1-D) model developed by Paul Johnson and Robbie Ettinger in 1991, based on earlier Radon work of Nazaroff and others.

$$Q_{eff}^{rad} (C_{source} - C_{ck}) = Q_{ck} \left(\frac{\exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) [C_{ck} - C_{indoor}]}{\exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) - 1} \right)$$

$$Q_{ck} = \frac{\exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) [C_{ck} - C_{indoor}]}{\exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) - 1} = Q_{building} + C_{indoor}$$

$$C_{indoor} = \frac{Q_{eff}^{rad} \exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D})}{\exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) + Q_{building} \exp(\frac{Q_{eff}^{rad} d_f}{A_{ck} D}) - 1} \frac{C_{source} - C_{indoor}}{Q_{building}}$$

Everything leaving the source enters the house- may not be realistic, but a consequence of 1-D.



Attenuation factor depends upon $Q_{building}$

REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures

Comparison of EPA JE results with full 3D

Deeper sources

$d_f = 2m$

$d_f = 0.1m$

Yao et al., *EST*, 45 2227-2235 (2011).

Neither calculation shown here took full account of capillary zone effects.

No consistent trend of over or underprediction. Often of same O.O.M., but not always...


Basement cases
Slab-on-grade cases



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Biodegradation Can be Handled



Abreu and Johnson,
EST, 40, 2304-2315
(2006)

$$0 = -\nabla \cdot (q_y c_{iy}) + \nabla \cdot (D_i \nabla c_{iy}) - R_i$$

$$R_i = \frac{\lambda_i \phi_w}{N_i} c_i c_o$$

Yao, 2012

$$\frac{dc_i}{dt} = -\frac{\lambda_i \phi_w}{N_i c_i} c_i c_o$$

**No agreement on
if c_o should be explicit
in models**



REUSE IN RHODE ISLAND
A State-Based Approach To Complex Exposures



Eric Suuberg
School of Engineering
Brown University

Eric_Suuberg@brown.edu
(401) 863 1420