



What Waste Site Cleanup Professionals Need to Know about Stormwater


**Presentation to
NEWMOA**

September 25, 2019

Stormwater 101 for Cleanup Professionals


- **Urban hydrology**
- **Water quality impacts & improvement**
- **Infiltration capacity, considerations, limitations**
- **Guidance document: stormwater infiltration systems in Connecticut urban fills**
- **Who to connect with in the states**

Hydrology



Water Quality Impacts

- Historical and new development
- Impaired coastal waters
 - Shellfish
 - Recreation
 - Fish/wildlife habitat
- Nonpoint sources
 - Stormwater runoff
 - Waterfowl
 - Marinas/boating



Water Quality Impacts

TMDLs

- About 40% of the nation's lakes, ponds, rivers, wetlands and coastal waters are listed as "impaired waters" because of point discharges (MADEP)
- Focus shift from nonpoint sources (urban and agricultural surface runoff) and subsurface sources (septic systems)
- Pollutant loads considered on a watershed scale
- Goal is to meet Water Quality Standards



Water Quality Impacts

TMDLs

Pollutant loads



Hydrology,
stream
hydraulics



Adsorption,
absorption,
other losses



Water
quality
standards

Federal requirement (Clean Water Act): if a water body doesn't meet State WQS for a pollutant a TMDL must be developed for ~~that~~ pollutant **Watershed scale**



Water Quality Improvements

Treatment:

- Physically adsorb onto a surface
- Biologically absorb into tissue
- Chemical alteration (to a less harmful state)
- Removal from system

Typical treatment targets:

- Bacteria
- Total suspended solids (TSS)
- Heavy metals
- Nutrients primarily nitrogen & phosphorus



Pollutant Removal Strategies

Pollutant removal tools:

- EPA performance and optimization tools
- University of New Hampshire
- Chesapeake Conservancy
- Interstate Technology Regulatory Council (ITRC)



<https://stormwater-1.itrcweb.org/>



ITRC BMP Screening Tool

ITRC Best Management Practices Screening Tool


- Pollutants of concern, environmental conditions, site restrictions, other factors



ITRCS&ENRUII

ITRC BMP Screening Tool

Pick pollutants – start with TSS



ITRCS&ENRUII

Infiltration considerations

Subsurface conditions

- Soil type and permeability
- Bedrock
- Groundwater depth
- Presence of Contaminated soil



Infiltration capacity

Determine infiltration rate

- Field Testing Requirements in “Soil Evaluation” of MA Stormwater Handbook
- Field analysis conducted by
 - MA-registered PE or
 - Engineer-in-Training (EIT) with civil degree or
 - Degree in Soil Science, Geology, or Groundwater Hydrology
- Methods
 - Permeameter
 - Infiltrometer
- Requires factor of safety of



Infiltration capacity

Determine infiltration capacity of management area:

- Empirical methods or numeric modeling
- Modeling based on Darcy's Law

- ✓ Energy gradient
- ✓ Hydraulic conductivity
- ✓ Surface area

USDA Soil Texture	Design Infiltration Rate (f_c) (in/hr)
Sand	8.27
Loamy Sand	2.41
Sandy Loam	1.02
Loam	0.52
Silt Loam	0.27

- Impacts of climate change

- ✓ Infiltration capacity is what it is
- ✓ Infiltration systems will see more frequent exposure to runoff
- ✓ Overflow to gravity system!



Considerations at contaminated sites

Current stormwater management practice is green infrastructure and low impact development, which rely on infiltration and groundwater recharge.

- Potential to mobilize contaminants and impact groundwater
- Can be overcome within regulatory framework
- Apply to new projects, redevelopment projects, retrofits of existing drainage systems



Guidance document – infiltration in urban fill

Grant provided by CT Institute for Resilience and Climate Adaptation (CIRCA).

- Policies and regulations regarding stormwater quality, Low Impact Development practices, stormwater management and work in urban soils are in separate documents and permit programs
- Develop a Design Guidance Checklist that summarizes and guides project planners and designers through the regulatory requirements
- Define tasks needed to evaluate and design stormwater management systems in urban areas that may contain urban fill
- Checklist is CT-centric but can be adapted for any state



Guidance document – infiltration in urban fill

1. Introduction
2. Purpose
3. Limitations
4. Design Guidance for Stormwater Infiltration at Sites Characterized by Urban Fill
5. Design Considerations
6. Environmental Considerations



Guidance document – infiltration in urban fill

1. Introduction

- Soils affected by history of development are sometimes referred to as urban soils or urban fill
- Burning of wood and coal, industrial activity byproducts - heavy metals, PAHs
- LID and GI address stormwater quality, groundwater recharge and flood resilience objectives. They can also mobilize contaminants and impact groundwater
- Permit programs – municipal, state (MS4 and waste management)



Guidance document – infiltration in urban fill

2. Purpose

- Provide guidance for project planners and designers on the siting and design of stormwater infiltration systems in urban settings with historical urban fill. Examples include bioretention basins, rain gardens, water quality swales, subsurface infiltration chambers and trenches
- Guide project planners and designers through the appropriate requirements of applicable regulatory practices and policies
- Improve consistency in planning, siting and design of LID and green infrastructure to meet water quality, flood resilience, and other objectives



Guidance document – infiltration in urban fill

- Raise awareness of the potential to encounter urban fill in areas of proposed stormwater management
 - Highlight the critical questions that should be asked to inform the design of an acceptable stormwater management system
 - Identify the regulatory requirements that could apply to the design and construction of stormwater infiltration systems in urban fill
3. Limitations of design guidance
- Users of this checklist must be knowledgeable and proficient in land use and planning, and in particular:




Guidance document – infiltration in urban fill

- Design and construction of stormwater management systems
- Characterization of contaminated soils and groundwater
- Construction cost estimating
- Management of contaminated soils and
- Familiarity with applicable local, state and federal regulations

4. Design Guidance

- Identifying urban fill areas
 - Walk through
 - Topographic maps, NRCS maps
 - Test pits or geotech borings
 - Collect & analyze soil samples, evaluate data vs. regulations



Guidance document – infiltration in urban fill

Design approach factors

- Level of contamination
- Land uses
- Classification / potential use of groundwater

Retention



Treatment



Guidance document – infiltration in urban fill

Design approaches

Retain, discharge to stream

- “Hold runoff on-site” for water quality event (1”)
- Used in land use activities with potential for spills or high pollutant loads
- Structures, filter with liner
- Discharge to gravity drainage system
- Examples
 - Tank
 - Oversized drainage pipe
 - Leaching system with lined sides and bottom

Treat and infiltrate

- Removal of sediment, floatables, and nutrients that may clog the system or “mask” soils and reduce infiltration over time
- Treated runoff infiltrates into soil
- Overflow - Discharge to gravity drainage system
- Examples
 - Infiltration basin
 - Surface Bioretention
 - Permeable pavement
 - Water quality swale



Design considerations

MAP Stormwater Handbook & Management Standards


- Design flow rates / water quality volume, peak flow management
- TSS removal
- Depth to groundwater
- Groundwater recharge – beware of tables and published recharge / infiltration rates!

Hydrologic Group Volume to Recharge (x Total Impervious Area)	
Hydrologic Group	Volume to Recharge x Total Impervious Area
A	0.60 inches of runoff
B	0.35 inches of runoff
C	0.25 inches of runoff
D	0.10 inches of runoff



Design considerations

Typical bioswale cross section



Design considerations

Design

Stormwater runoff model

- 1D (HydroCAD), 2D (PCSWMM)
- Calibration if possible

Design capacity

- On-site vs. off-site watershed contributions
- Design return frequency (high)
- Overflow to gravity outlet (low frequency storm)

Groundwater recharge

- Stormwater management requirements
- Soil infiltration capacity (determine in-situ or in lab)

System footprint, constructability, other factors



Who to contact

Local stormwater authority

State stormwater authority and permitting

Groundwater program

Waste management program



Questions

My contact information:

Phil Forzley, PE

Fuss & O'Neill, Inc.

pforzley@fando.com

860.748.1367